Catalog

Auto-induction A/B.....1
Restore Factory Settings/ Output Mode / Language Settings.....2-3
Serial port Settings.....3
Bar code Type Settings.....4
UPC/EAN Attached Code Settings.....5
Bar code Prefixes and suffix Settings.....6
Parameter Code.....7
Parameter Code and Corresponding representing Characters Table...8
Warranty Instruction.....9
Maintenance Record.....10-11

Respected Clients:

Thanks for choosing us. We have two auto-induction besides ordinary wired CCD barcode scanner. The two have the following characteristics respectively:

1.Auto-induction A

Needs to use with stand. Hang the scanner over the stand and auto-induction opens. Withour stand it is used as an ordianry wired scanner. (Notes: The auto-induction function is yumite unique technology)

2.Auto-induction B

Needs to press the switch for 10s and auto-induction opens. If keep pressing the switch for antoher 10s, the function of auto-induction will be closed.

The stand can be optional for users. (Notes: Do not use it as an ordinary wired scanner after opening auto-induction. Please close auto-induction if you need to use it as an ordinary wired scanner.)

Special notes:

In order for users to read this user manual, we delete all complicated operations for easy of use.

Restore Factory Settings

Enter Into Settings

Factory Default

Quit Settings

Attention: Before any function settings ,please read the barcode of "Enter Into Settings" and th en read the barcode of needed function settings and finally please read the barcode of "Quit Settings".If there is any needless function or parameter which is set before, please read the barcode of "Factory Default" to restore the factory settings.

Output Mode

Flicker Scanning

Flicker Scanning Time

USB Virtual Keyboard

Attention: The time of the flicker scanning can be set through reading the ″Parameter barcode″ 01-09. The procedures reading the barcode successively as ″Enter Into Settings″, ″Flicker Scanning Time″, ″Parameter barcode″, ″Quit Settings″.

Keyboard Languages Settings

English

American English

French

Danish

Check Settings

No Check

Odd Check

Even Check

Bar Code Type Settings

Open The Code ID Before Bar Code

Close The Code ID before Bar Code

Attention: The Code ID before the bar code means the corresponding bar code type, pleae check the Sheet1-1

Bar code Type	Code ID
Code 128	j
UCC/EAN-128	u
AIM 128	f
ISBT 128	t
EAN-8	g
EAN-13	d
ISSN	n
ISBN	B
UPC-E	h
UPC-A	c
Interleaved 2 of 5	e
ITF-6	r
ITF-14	q

Bar code Type	Code ID
Deutsche 14	w
Deutsche 12	l
COOP 25（Japanese Matrix 2 of 5）	o
Matrix 2 of 5(European Matrix 2 of 5)	v
Industrial 25	i
Standard 25	s
Code 39	b
Codabar	a
Code 93	y
Code 11	z
Plessey	p
MSI-Plessey	m
GS1 Databar	R

Finnish

Japanese

Norwegian

Turkish F

Turkish Q

Italian

Spanish

Serial Port Settings(Baud Rate Settings)

Enter into Settings

Quit Settings

9600

2400

4800

14400

19200

38400

57600

115200

Enter into Settings

Quit Settings

UPC/EAN- Attached Code settings

Adding Two Bit Attached Code

Adding Five Bit Attached Code

Code39 to or not to transmit start character and stop character

to Transmit

Not to Transmit

Enter-Line Skip Settings

Enter

Enter-Line Skip

Enter into Settings

Quit Settings

Add Prefix Setting

Add Prefix

Reveal Prefix

Not Reveal Prefix

For example: if add prefix "XY" before code"1234", steps as follows:
1. Enter into Settings 2. Add Prefix 3. read parameter code 5,8,5,9 and then read "Save" 4. Quit Settings
After above settings and read "Reveal Prefix" code, when read code"1234"again the"XY" will be added, change to: XY1234.

Add Suffix Settings

Add Suffix

Reveal Suffix

Not Reveal Suffix

For example: if need to add suffix "XY" after code"1234", steps as follows:
1. Enter into Settings 2. Add Suffix 3. read parameter code 5,8,5,9 and then read "Save" 4. Quit Settings
After above settings and read "Reveal Suffix" code, when read code"1234"again the"XY" will be added, change to: 1234XY.

Parameter Code

0

1

2

3

4

5

6

7

8

9

A

B

C

D

E

F

Save

Add Suffix-Enter

ASCII code Setting (PS: This setting aims to code 39 reading incompleted characters.)

Close

Open

Parameter barcode and corresponding representing characters table.

Parameter code	Representing characters	Parameter code	Representing characters	Parameter code	Representing characters	Parameter code	Representing characters	Parameter code	Representing characters
2 d	-	4 4	D	5 b	[	7 2	r	2 b	+
2 e	.	4 5	E	5 c	\	7 3	s	2 c	,
2 f	/	4 6	F	5 d	]	7 4	t		
3 0	0	4 7	G	5 e	^	7 5	u		
3 1	1	4 8	H	5 f	_	7 6	v		
3 2	2	4 9	I	6 0	'	7 7	w		
3 3	3	4 a	J	6 1	a	7 8	x		
3 4	4	4 b	K	6 2	b	7 9	y		
3 5	5	4 c	L	6 3	c	7 a	z		
3 6	6	4 d	M	6 4	d	7 b	{		
3 7	7	4 e	N	6 5	e	7 c	|		
3 8	8	4 f	O	6 6	f	7 d	}		
3 9	9	5 0	P	6 7	g	7 e	~		
3 a	:	5 1	Q	6 8	h	2 1	!		
3 b	;	5 2	R	6 9	i	2 2	"		
3 c	<	5 3	S	6 a	j	2 3	#		
3 d	=	5 4	T	6 b	k	2 4	$		
3 e	>	5 5	U	6 c	l	2 5	%		
3 f	?	5 6	V	6 d	m	2 6	&		
4 0	@	5 7	W	6 e	n	2 7	`		
4 1	A	5 8	X	6 f	o	2 8	(		
4 2	B	5 9	Y	7 0	p	2 9	)		
4 3	C	5 a	Z	7 1	q	2 a	*		

About the Warranty

1.Since you buy our product with this card,you can enjoy the service of one year repair and lifelong maintenance for the rubber and plastic parts of the barcode scanner,6 months repair service for the battery and the charger,and 3 months repair service for the data cable.During the repair period,the maintenance of the product is free.Expire the warranty, we will charge the replaced components and maintenance cost;

2.If the product belongs to one of the below situations and verified by manufacturer,the user can't enjoy the free maintenance service:

a.Expire the warranty period;

b.The barcode scanner body is disassembled or the camera of the scanner is damaged;

c.The surface or internal component of the scanner is seriously damaged;

d.The product is damaged due to the wrong installation or operation;

e.The serial number of the scanner is altered or does not conform to the number written on the card.

f.The scanner is damaged due to an artificial fault.For instance, it is inundate.

g.The scanner is damaged due to natural disasters,e.g. fire disaster, flood and thunder stroke.

h.The working or storage environment of the product,e.g. temperature or humidity,does not conform to the requirements in Operation Manual.

Thank You For Choosing Our Products!

XV.

User Information		Distributor Information	
Name		Name	
Address		Address	
Zipcode		Zipcode	
Tel		Operator Signature	
Email		Distributor Seal	

Appendix

Accessories Name	Quantity
Scanner	1
With Stand(Auto-induction A/B optional)	1
USB Charge Cable	1
Manual	1

Maintenance Record

Barcode Reader		Warranty Card
	Part No.	
	Serial No.	
	Purchase Date	

Date	Fault Descriptio	Maintenanc e Record	Operator

Please make sure to read the instructions about maintenance carefully at the back of the card. Fill out various data above carefully and the file vaild only if it is signed with the offical of the authorized dealer.